



NOTE:

BLAST-IT-ALL's specially designed tubular dust bag is installed by pushing end of bag into hole far enough to allow springs to snap into place. The bags fit extremely tight to form a perfect filtering media to control dust leakage.

***CAUTION:**

Do not use a sharp instrument to force snapsprings into hole. Install one bag at a time starting with the rear halves and working forward.

Item #	400 CFM	700 CFM	900 CFM	Description
1	19-094	19-096	19-097	Flex Hose
2	21-035	21-036	21-037	Clamp
3	19-303	19-300	19-302	Inlet Damper
4	11-364 (18)	11-364 (30)	11-364 (42)	Bag
5	19-301	19-301	19-301	Filter
6	24-025	24-025	24-025	Gasket (Specify Length)