# **CLEAN BENCH™**

LARRY HESS AND ASSOCIATES, INC.
BLAST-IT-ALL®
P.O. BOX 1615
SALISBURY, NC 28145
WWW.BLAST-IT-ALL.COM

# **CLEAN BENCH**<sup>TM</sup>

# WITH DUST COLLECTOR

# MANUAL MM 567

## TABLE OF CONTENTS

PAGE	FIGURE	
1	_	SET-UP INSTRUCTIONS
1		OPERATING INSTRUCTIONS
1	_	GENERAL MAINTENANCE
2	м159	PART NUMBERS
3	_	ELECTRICAL DIAGRAM
4	_	MACHINE WARRANTY
5	_	WARRANTY REGISTRATION FORM

#### **CLEAN BENCH™**

### **SET-UP INSTRUCTIONS**

## MACHINES WITH CARTRIDGE TYPE DUST COLLECTORS

#### \*\*\* READ BEFORE OPERATING EQUIPMENT \*\*\*

- 1. Remove all shipping protection. Check for any concealed shipping damage, if discovered, report to damage to your freight carrier immediately.
- 2. CLEAN BENCH should be placed in a desired location, away from any water or wet environment.
- 3. Install Cartridge Dust Collector: Packaged with machine is flex hose and clamps. Place duct collector next to the bench. Attach the flex hose to the sump outlet.
- 3. Plug electrical cord from side of dust collector into top receptacle.

## **OPERATING INSTRUCTIONS**


- 1. All parts to be processed must be free of oil, grease, and moisture. Make sure parts are dry before cleaning.
- 2. Place part to be cleaned over the grate area and clean.


# OPERATING AND SERVICING CARTRIDGE DUST COLLECTOR

A SINGLE SWITCH OPERATES THE FAN MOTOR AND THE LIGHTS.

## **MAINTENANCE INSTRUCTIONS**

- 1. Poor Visibility Excessive Dust:
- A. Air inlet blocked, check for blockage.
- B. Dust collector drawer full and needs emptied.
- **C.** Cartridge contaminated. REPLACE CARTRIDGE.
- 2. TO REPLACE CARTRIDGE, REMOVE THE HEPA AND FAN SECTION.





#### WARRANTY

Larry Hess & Associates, Inc. Warrants to the original purchaser the merchandise sold to be free from defects in material and workmanship under normal use and service for a period of one (1) year. Upon prompt notification by the buyer, to LHA, components that are determined by LHA to be defective will be repaired or replaced at no additional charge, F.O.B. our factory.

Manufacturer shall have the right to inspect prior to replacing all merchandise in question.

This warranty does not apply to parts that are directly involved in the blasting operation. Example: gun, gun parts, viewing window, hose, gloves, etc.

Manufacturer shall not be required to pay any removal or installation charges whatsoever under this warranty.

Manufacturer shall not be liable for prospective profits, special or consequential damages, nor shall any recovery of any kind against manufacturer be greater in amount than the cost of repairs of defects in workmanship.

This warranty does not apply to damage caused by accidents, damage in transit, alterations by unauthorized personnel, abuse or damage by flood, fire, or acts of God, nor by artificially generated electric currents or any other cause whatsoever except defects in material or factory workmanship.

In all cases, defective parts must be returned to Larry Hess & Associates, Inc. before credit is issued.

If genuine BLAST-IT-ALL® replacement parts are not used, the warranty is void.

This warranty is in lieu of all other warranties expressed or implied and releases Larry Hess & Associates, Inc. of all other obligations and liabilities whatsoever. This warranty neither assumes nor authorizes any person to assume any obligation other than those specified by this warranty.

WARNING

DO NOT USE **SAND**. SAND WILL CAUSE SILICA DUST, WHICH IS THE CAUSE OF SILICOSIS DISEASE, A CONDITION OF MASSIVE FIBROSIS OF THE LUNGS. **THIS STATEMENT INDICATES POTENTIAL PERSONNEL HAZARD. FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY.** 

BLAST-IT-ALL® Larry Hess & Associates, Inc. Airport Industrial Park 185 Piper Lane P.O. Box 1615 Salisbury, NC 28145-1615